

Vacuumsauger ERA EVO – Initial Operation & Safety Instructions.



NORDBERGER

Gebäude-/Industrie-/Personal-Service

Wir können das!

Initial operation:

- ✓ Place the device on a stable, flat ground.
- ✓ Adjust the floor nozzle to the floor conditions.

Visual inspection:

- ✓ Check the device and power cable for damage.
- ✓ Check if all filter elements are correctly mounted.
- ✓ Check the collection container or dust bag for fill level.
- ✓ Check the floor nozzle for heavy contamination to protect the surfaces to be cleaned.
 - ✓ Clean the floor nozzle if necessary.

Connection:

- ✓ Connect to a suitable power source – check that the main switch is „Off“ before connecting.
- ✓ Pull the cable to the desired operating radius.

Operation:

- ✓ Adjust the telescopic tube individually.
- ✓ Switch on the device via the foot switch.
- ✓ Clean the floor:
 - ✓ Clean hard-to-reach areas with the crevice tool.
- ✓ After cleaning, switch off the device via the foot switch.
- ✓ Disconnect the power connection from the power source.
- ✓ Carefully retract/roll up the cable.

Maintenance:

- ✓ Empty the collection after each cleaning.
- ✓ Regularly replace the dust bag when full.
- ✓ Regularly change the integrated filters.
- ✓ Regularly clean the housing using a damp microfiber cloth (water without additives).



Safety Instructions:

- ✓ Use the device only for its intended purpose.
- ✓ Do not use in case of:
 - ✓ Damaged cable.
 - ✓ Visible defect.
- ✓ Repairs only by:
 - ✓ Qualified personnel
 - ✓ Employer.

